







Barkbusters

VPS-BMW F650 FITTING INSTRUCTIONS

1. Remove the original plastic handguards and bar end weights from the handlebars. Also remove the cable ties from the handlebar to free up the cables and handlebars during the installation process.
2. Remove the centre switch panel from above the handlebar mounting bolts (if fitted) by unscrewing the four 5mm screws. Remove the four bolts that hold the handlebar to the top triple clamp.
3. Lift up the handlebar and fit the two 20mm raisers between the bottom of the handlebar and the top triple clamp. **Note:** the holes in the raisers are offset and must be fitted in the correct direction so the holes line up with the threaded holes in the triple clamp. (See Diagram 1.)
4. Secure the handlebar with supplied longer bolts and tighten to 20 newton meters. Refit centre switch panel.
5. Loosely assemble the clamps to the handlebar (See Diagram 2 front view & 6 rear view).
Note: the accelerator cable holder (10) should be positioned below the clamp.
6. Insert the special M6x25 bolt (1)(See Diagram 3) through the outer end of the Barkbusters bar (4), the supplied bar end weight (2) and screw it into the handlebar end (3). Tighten enough to hold in position. **Note:** We recommend applying a mild thread locking compound to the threads of bolts 1 and 6 before fitting.
7. Fit the inner end of the Barkbusters bar to the connecting arm (9) of the clamp. (See Diagram 2 & 6.) Position the handguards so you are comfortable with the fit. **Note:** you may need to adjust the position of the handguards and the handlebars a little so the handguards do not touch the fairing or instruments when the steering is at full lock.
8. Tighten all bolts including the handlebar end bolts. **Important:** The clamp bolts must be tightened in the following order. (See Diagram 2).
Tighten bolt (6) through the handguard to the connecting arm (9).
Tighten bolt (7) to solidly lock the connecting arm between the two halves of the clamp.
Tighten bolt (8) to secure the clamp firmly to the handlebar. (Note: The clamp is designed to allow the nut on bolt (7) to pull into the recessed hole. This eliminates the need to hold the nut after the bolt starts to tighten.)
9. Thread a cable tie through the supplied black plastic spacer (5) around the electrical cables, back through the spacer and around the handlebar raiser. Tighten as shown in diagram 4. **Note:** this is to hold the wiring in position so it will not be pulled tight when the steering is turned.
10. The accelerator cable should be located between the two ABS hose fittings on the left side of the steering head.



Important: check the routing and free play of all cables when the steering is at left and right full lock. Re-route or pull through extra cable of any cables that are tight and recheck that all cables have sufficient free play on both steering locks.

WARNING: Check operation of all handlebar controls, specifically the throttle, front brake, kill switch and clutch to ensure they are operating correctly and are in accordance with the OEM specifications. Do not ride the motorcycle if any controls are not operating correctly or if rear view mirror vision is obscured. Check periodically that all bolts are tight.

Disclaimer: Rideworx inspects all products prior to packaging and strives toward improving its products. Our guarantee is limited to the replacement of defective products. This limited guarantee is in lieu of all other guarantees or warranties implied or expressed. Buyer assumes all risk for any and all damage caused to him/herself, a third party and/or property by virtue of failure of this product. We make no warranty as to products distributed by Rideworx, expressed or implied from our suppliers or third party vendors. This includes, without limitation, any warranties or merchantability and fitness for a particular purpose. All products are offered and designed for use with standard machines. Rideworx makes no claims as to the products effectiveness on modified machines. Rideworx is the sole determiner of abuse, misuse, installation errors and modifications. We assume no liability for any errors in listings, specifications, part numbers, prices or model applications. We reserve the right to change specifications, product descriptions, product quality, pricing and application at any time without notice and without further obligation. These handguards are not designed to prevent injury in the event of an accident or crash. Ensure all controls are free of the handguards each time you ride. Failure to follow the instructions or heed this warning could lead to loss of control of your motorcycle and/or accident, injury or death. By installing and/or using a Rideworx product, you hereby accept and understand these stated terms and conditions and have followed all instructional steps.



3/7 Luso Drive, Unanderra NSW 2526, Australia
T: +61 2 4271 8244, F: +61 2 4271 8255
Email: info@barkbusters.net, Web: www.barkbusters.net

