

# BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2009 by Big Bike Parts, Inc.® No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.®

TWISTED CRUISER

MIRRORS

PART NO. 28-101 & 28-102

10MM MOUNT

FOR HONDA,  
KAWASAKI, SUZUKI  
CRUISERS

REVISED 08-07-13

TOOLS REQUIRED: 17MM WRENCH, 2MM ALLEN WRENCH, 13MM SOCKET

## INSTALLATION:

1. USING THE 17MM WRENCH LOOSEN THE NUT THAT HOLDS THE MIRRORS ON. SPIN THE WHOLE MIRROR ASSEMBLY TO TAKE IT OFF.
2. THREAD THE NEW MIRRORS INTO THE BIKE. DO NOT TIGHTEN.
3. POSITION THE MIRRORS INTO THE DESIRED POSITION FOR VIEWING COMFORT.
4. ONCE MIRRORS ARE IN THE DESIRED POSITION, TIGHTEN THE 17MM NUT THAT HOLDS THE MIRROR STEMS IN PLACE.
5. TO TIGHTEN MIRROR HEAD USE A 2MM ALLEN WRENCH TO REMOVE THE 2 SCREWS HOLDING THE MIRROR HEAD TO THE MIRROR STEM.
6. USING A 13MM SOCKET SLIGHTLY TIGHTEN THE NUT ON THE END OF THE MIRROR STEM AND REASSEMBLE MIRROR HEAD.

NOTE: WE RECOMMEND USING REMOVABLE THREAD LOCK COMPOUND ON ALL THREADS.